



Cell Outline

Type DX, DXC



CELL TYPE	PLATES PER CELL	H	FIGURE NO.
DX/DXC	5,7,9	21.9 (557)	1
	11,13,15,17	22.7 (576)	2
	19		3
	21,23,25		4
	27 TO 35		5




FIG. #1
5,7,9 Plate




FIG. #2
11,13,15,17 Plate




FIG. #3
19 Plate




FIG. #4
21,23,25 Plate




FIG. #5
27 to 35 Plate



Global Headquarters: P.O. Box 14145, Reading, PA 19612-4145
1-610-208-1991 • 1-800-538-3627
FAX 1-610-372-8613

US Sales Offices
Eastern Region: 1-800-346-4402 • 1-215-491-3700
Western Region: 1-800-423-4667 • 1-562-949-4266

Regional Sales Offices
EnerSys Canada: 1-905-790-1212
ESB de Mexico SA DE: 52-8-329-6405

EnerSys Inc. has locations worldwide to serve your needs:
for additional information please visit our website at
www.enersysinc.com or contact us at 1-800-538-3627.