


**Non-Seismic
12HX330**

Battery Rack

5 TIER RACK SHOWN



**AZMS UAC1 – 1 Tier
UAC2 – 2 Tier
UAC3 – 3 Tier
UAC5 – 4 Tier
UAC9 – 5 Tier**

LENGTH Blocs per Row	ROWS per TIER	HEIGHT	CATALOG NO.	DIMENSIONS				UNPACKED WEIGHT		PACKED WEIGHT	
				L		C		lbs	kg	lbs	kg
				in	mm	in	mm				
4 BLOCS	1	1 TIER	U12HX3304J1TZ0A	29.5	749	25.3	643	41	19	91	41
	1	2 TIER	U12HX3304J2TZ0A					68	31	118	54
	1	3 TIER	U12HX3304J3TZ0A					96	44	146	66
	1	4 TIER	U12HX3304J4TZ0A					218	99	268	122
	1	5 TIER	U12HX3304J5TZ0A	30.2	767	267	121	317	144		
5 BLOCS	1	1 TIER	U12HX3305J1TZ0A	36.5	927	32.2	818	46	21	96	44
	1	2 TIER	U12HX3305J2TZ0A					76	35	126	57
	1	3 TIER	U12HX3305J3TZ0A					107	49	157	71
	1	4 TIER	U12HX3305J4TZ0A	37.1	942	244	111	294	133		
	1	5 TIER	U12HX3305J5TZ0A	37.1	942	298	135	348	158		
6 BLOCS	1	1 TIER	U12HX3306J1TZ0A	43.4	1102	39.1	993	51	23	101	46
	1	2 TIER	U12HX3306J2TZ0A					85	39	135	61
	1	3 TIER	U12HX3306J3TZ0A					118	54	168	76
	1	4 TIER	U12HX3306J4TZ0A	44.0	1118	269	122	319	145		
	1	5 TIER	U12HX3306J5TZ0A	44.0	1118	329	149	379	172		
10 BLOCS	1	1 TIER	U12HX330101TZ0A	71.0	1803	66.8	1697	71	32	121	55
	1	2 TIER	U12HX330102TZ0A					118	54	168	76
	1	3 TIER	U12HX330103TZ0A					164	74	214	97
	1	4 TIER	U12HX330104TZ0A	71.7	1821	373	169	423	192		
	1	5 TIER	U12HX330105TZ0A	71.7	1821	455	206	505	229		

RACK SPECIFICATIONS:

FRAMES: Steel members covered with gray acid-resistant polyester powder coating
HARDWARE: Zinc-plated steel – RoHS compliant



RACK NOTES:

- Racks are shipped unassembled. All necessary assembly hardware is included – see note 2.
- Each frame must be anchored to the floor. Holes are provided at the base of each frame. Please refer to rack diagram for hole size and spacing. Determining the anchor bolt size and supplying the anchor bolts is the responsibility of the customer.
- For rack installation instructions, please refer to EnerSys® Publication No. US-HXRACK-IM, *Instructions for Assembling DataSafe™ HX UBC Battery Racks*.



EnerSys
P.O. Box 14145
Reading, PA 19612-4145
USA
Tel: +1-610-208-1991
+1-800-538-3627
Fax: +1-610-372-8613

EnerSys EMEA
Brussels, Belgium
Tel: +32 (0)2 247 94 47
EnerSys Asia
Guangdong, China
Tel: +86 755 2689 3639

Represented by: