


**Non-Seismic
12HX400**

Battery Rack

5 TIER RACK SHOWN



- AZMS UAD1 – 1 Tier**
- UAD2 – 2 Tier**
- UAD3 – 3 Tier**
- UAD5 – 4 Tier**
- UAD9 – 5 Tier**

LENGTH Blocs per Row	ROWS per TIER	HEIGHT	CATALOG NO.	DIMENSIONS				UNPACKED WEIGHT		PACKED WEIGHT	
				L		C		lbs	kg	lbs	kg
				in	mm	in	mm				
4 BLOCS	1	1 TIER	U12HX4004J1TZ0A	29.5	749	25.3	643	42	19	92	42
	1	2 TIER	U12HX4004J2TZ0A					70	32	120	54
	1	3 TIER	U12HX4004J3TZ0A					98	45	148	67
	1	4 TIER	U12HX4004J4TZ0A					222	101	272	123
	1	5 TIER	U12HX4004J5TZ0A	30.2	767	272	123	322	146		
5 BLOCS	1	1 TIER	U12HX4005J1TZ0A	36.5	927	32.2	818	47	21	97	44
	1	2 TIER	U12HX4005J2TZ0A					78	35	128	58
	1	3 TIER	U12HX4005J3TZ0A	109	49			159	72		
	1	4 TIER	U12HX4005J4TZ0A	248	113			298	135		
	1	5 TIER	U12HX4005J5TZ0A	37.1	942			303	137	353	160
6 BLOCS	1	1 TIER	U12HX4006J1TZ0A	43.4	1102	39.2	996	52	24	102	46
	1	2 TIER	U12HX4006J2TZ0A					86	39	136	62
	1	3 TIER	U12HX4006J3TZ0A					120	54	170	77
	1	4 TIER	U12HX4006J4TZ0A	273	124			323	147		
	1	5 TIER	U12HX4006J5TZ0A	44.0	1118			334	152	384	174
10 BLOCS	1	1 TIER	U12HX400101TZ0A	71.1	1806	66.9	1699	73	33	123	56
	1	2 TIER	U12HX400102TZ0A					120	54	170	77
	1	3 TIER	U12HX400103TZ0A	166	75			216	98		
	1	4 TIER	U12HX400104TZ0A	377	171			427	194		
	1	5 TIER	U12HX400105TZ0A	71.8	1824			459	208	509	231

RACK SPECIFICATIONS:

- FRAMES:** Steel members covered with gray acid-resistant polyester powder coating
- HARDWARE:** Zinc-plated steel – RoHS compliant



RACK NOTES:

1. Racks are shipped unassembled. All necessary assembly hardware is included – see note 2.
2. Each frame must be anchored to the floor. Holes are provided at the base of each frame. Please refer to rack diagram for hole size and spacing. Determining the anchor bolt size and supplying the anchor bolts is the responsibility of the customer.
3. For rack installation instructions, please refer to EnerSys® Publication No. US-HXRACK-IM, *Instructions for Assembling DataSafe™ HX UBC Battery Racks*.



EnerSys
P.O. Box 14145
Reading, PA 19612-4145
USA
Tel: +1-610-208-1991
+1-800-538-3627
Fax: +1-610-372-8613

EnerSys EMEA
Brussels, Belgium
Tel: +32 (0)2 247 94 47

EnerSys Asia
Guangdong, China
Tel: +86 755 2689 3639

Represented by: